

Double Speed Progressive Scan CCD Camera

Operation Manual

(Rev.C)

CE

DECLARATION OF CONFORMITY

AS DEFINED BY THE COUNCIL DIRECTIVE

89/336/EEC EMC (ELECTROMAGNETIC COMPATIBILITY)

WE HEREWITH DECLARE THAT THIS PRODUCT

COMPLIES WITH THE FOLLOWING PROVISIONS APPLYING TO IT.

EN-50081-1

EN-50082-1

Table of Contents

CE declaration	. 2
1. General	. 4
2. Main features	. 4
3. Standard composition	. 4
4. Location and functions	5
5. Pin assignment	. 6
5-1 12 pin connector (DC IN/SYNC connector)	. 6
5-2 6 pin connector (TRIGGER connector)	. 7
6. Functions and operations	
6-1 Input/output of HD/VD signal	
6-2 Ext. trigger/readout mode	. 8
7. Mode setting	
7-1 SW1 switch on the rear panel	
7-2 Jumpers on board	17
8. External appearance	20
9. Specification	21
10. Appendix	22
11. User's Record	23

1. General

The CV-M40 is a 1/2" CCD progressive scan camera, incorporating double speed and partial scan techniques, housed in a compact and robust package.

Using the latest CCD sensor technology with square pixels provides excellent resolution and signal to noise ratio, together with flexible asynchronous random trigger functions and multitude of user settings.

2. Main Features

- 1/2" IT monochrome CCD sensor
- 654 (h) x 494 (v) x 9.9 μm square pixels (compatible with VGA format)
- 60 full progressive frames per second over a single video output
- 120 frames per second using vertical binning (half vertical resolution, pixel aspect ratio 1:2)
- Internal, external, HD/VD or random synchronization
- 3 external trigger/readout modes : Edge pre-select, pulse width and frame-delay readout
- Shutter speed 1/125 to 1/12,000
- 24.5 MHz pixel frequency and 31.468 kHz line frequency
- Video output with or without sync.
- Set-up by RS 232C or switches
- Up to 233 frames per second with partial scan (user selectable)

3. Standard composition


1)	Camera main body	x 1
2)	Tripod mount plate (MP-40)	x 1

3) Operation manual x 1

Optional accessories

- 1) 12 pin connector (HR10A-10P-12S-01)
- 2) 6 pin connector (HR10A-7P-6S)

4. Locations and functions



- 3. BNC connector
- 4. SW1 switch
- 5. 6 pin multi connector
- 6. 12 pin multi connector
- 7. Gain potentiometer
- 8. Tripod mount plate
- 9. Screw holes for Tripod mount plate


Video output (VS 1.0 Vpp at 75 Ohm) :

- Shutter speed and function modes selection
- RS 232 input and output / ext. trig input :
- +12V DC power / video output / sync. input and output
- Gain level adjustment

When you mount the camera on your system, please make sure to use screws which have the length less than 5 mm from the camera bottom plate, as it may cause a serious damage to the PCB inside the camera when the length is more than 5 mm.

•

Please be advised that the supplied 4 screws for Tripod mount plate are to be used exclusively for MP-40, but not for any other mounting adaptor.




IR-cut filter

CAUTION

5. Pin assignment

5-1. 12 pin connector (DC IN/SYNC connector)



HR10A-10R-12PB-01 (Hirose) male


Pin No.	Ext Sync Mode (Factory setting)	Ext Trigger Mode H-Reset	Ext Trigger Mode H Non-reset	Int Sync Mode					
1	GND								
2		DC+1	2V IN						
3		GND(\	/IDEO)						
4		VIDEO) OUT						
5	GND								
6*	Ext.HD IN	Ext.TRIG IN	Ext.HD IN	Int.HD OUT					
7*	Ext.VD IN	WEN OUT	Ext.TRIG IN	Int.VD OUT					
8		GI	ND						
9*	NC	PLCK/WEN OUT	PLCK/WEN OUT	NC					
10		GND							
11	DC+12C IN								
12	GND								

* Note : To change the signal output on pin no. 6, 7 and 9, it is necessary to make jumper setting. See "7-2. Jumpers on board" for more informations.

Pin no.	Factory pre-set	Others
6	HD input	HD output
7	VD input	VD output
9	NC	Pixel clock output

- 1. When trigger signal is input at #5 of 6 pin multi connector, do not input/output HD signal at #6 of 12 pin multi connector, as it causes a failure in Ext. trigger mode.
- 2. Do not use video output at the same time both from #4 of 12 pin multi connector and BNC connector, as it causes a failure on video signal due to double termination.

5-2. 6 pin connector (TRIGGER connector)



HR10A-7R-6P (Hirose) male

Pin no.	HD/VD input or output	Ext. trigger/readout				
1	TXD output					
2	RXD input					
3	Ground					
4	Gro	und				
5*	**See note 2.	2. Ext. trigger input				
6*	WEN output					

* Note : 1. To change the signal output on pin no. 5 and 6, it is necessary to make jumper setting. See "7-2. Jumpers on board" for more informations.

Pin no.	Factory pre-set	Others		
5	Trigger input	NC		
6	WEN output	NC		

2. Do not input HD or VD signal at pin no.5, when the camera is set at Continuous mode.



CAUTION

When trigger signal is input at #5 of 6 pin multi connector, do not input/output HD signal at #6 of 12 pin multi connector, as it causes a failure in external trigger mode.

6. Functions and operations

6-1. Input/output of HD/VD signal

a) Input of external HD/VD signal (Factory pre-set)

To input ext. HD/VD signal, make JP9/JP11 short-circuited, and JP12/JP13 open-circuited. To change the termination of ext. HD/VD signal, it is neccessary to make the jumper JP8/JP10 short-circuited. All jumpers are located on PK8273 board. For details, please refer to 7-2-3. Jumpers on PK8273 board.

Note : Factory pre-set is set at HD/VD input (TTL) .

b) Output of internal HD/VD signal

To output int. HD/VD signal, make jumper JP9/JP11 open-circuited, and JP12/JP13 short-circuited. All jumpers are located on PK8273 board. Please refer to 7-2-3. Jumpers on PK8273 board.

Int. HD/VD signal is effective only at 75 Ohm termination.

6-2. Ext. trigger/readout mode

Ext. trigger mode of CV-M40 allows 3 different driving modes, as follows.

Edge pre-select trigger mode	:	Asynchronous reset by the external trigger pulse Exposure period controlled by 8-step fixed shutter steps
Pulse-width control mode	:	Asynchronous reset by the external trigger pulse Exposure period controlled by the pulse width of the external trigger pulse.
Frame-delay readout mode	:	Asynchronous reset by the external trigger pulse Exposure period controlled by 8 fixed shutter steps Video readout timing controlled by rising edge of the external trigger pulse.

6-2-1. Edge pre-select mode

In this mode, the exposure starts at the falling edge of the external trigger pulse. The WEN pulse originates from the camera.

The shutter speed is controlled by the SW1 switch on the rear panel of the camera and the RS 232C serial interface.

For details, refer to the timing charts section of this manual.

To use this mode, set up the camera as follows ;

- a) Set SW1-5 at ON, and SW1-6 at OFF to select the Edge pre-select mode.
- b) Set SW1-1 to SW1-3 to select the appropriate shutter speed. For controlling the shutter speed by the RS 232C serial interface, set SW1-8 at ON.
- c) Set the SW1-4 switch to ON to select the Binning mode and set the switch SW1-7 to OFF to select the Partial scan mode.

The pulse width of the external trigger pulse must be 2H to 1300H.

6-2-2. Pulse width control mode

In this mode, the exposure time is controlled by the pulse width of external trigger pulse. The exposure starts at the falling edge of the external trigger pulse and ends at the rising edge of the external trigger pulse. The WEN pulse is generated and output from the camera. For details, refer to the timing charts section of this manual.

To use this mode, set up the camera as follows ;

- a) Set SW1-5 at OFF, and SW1-6 at ON to select the Pulse width control mode.
- b) Set the SW1-4 switch to ON to select the Binning mode and set the switch SW1-7 to OFF to select the Partial scan mode.



The pulse width of the external trigger pulse must be 2H to 525H.

6-2-3. Frame-delay readout mode

In this mode, the timing of the video output is controlled by the width of the external trigger pulse. The exposure starts at the falling edge of the external trigger pulse and ends according to the shutter setting. The video signal is output at the rising edge of the external trigger signal. The WEN pulse is generated and output from the camera.


For details, refer to the timing charts section of this manual.

To use this mode, set up the camera as follows ;

- a) Set SW1-5 at ON, and SW1-6 at ON to select the Frame-delay readout mode.
- b) Set SW1-1 to SW1-3 to select the shutter speed.
- c) Set the SW1-4 switch to ON to select the Binning mode and set the switch SW1-7 to OFF to select the Partial scan mode.




The minimum value of pulse width for the external trigger pulse depends on the exposure time, as follow. Minimum : pulse width (more than 3H) > exposure time 6-2-4. Timing charts 1. Video out (H)



2. Ext. sync mode

Note 1:Sync or HD is not mentioned Note 2:1H=31.777 μ S Note 3:WEN polarity can be chosen at JP22 of I/F board



2-b) Binning readout(1/120sec.1frm=262H,120frm/sec.)

2-a) Normal readout(1/60sec.1frm=525H,60frm/sec.)

Ext.HD		
Ext.VD		
VIDEO OUT	▼ 8.5H ►	
WEN(positive)	10H 242H Valid period	
-		
WEN(Negative)		

CV-M40


2-c) Partial Scan							
Ext.VD							
Int.VD	<u>↓</u>					9H	-
Video out	gn ·						
	⊢ A ►		Valid peri	od	_		
WEN (Positive) <u>IH</u>			В			C T	
WEN (Negative)	7H►						
	Effective readout line	А	В	С		e 1:Sync or HD is not mentior e 2:1H=31.777 μ S	ned
	240 line	44H	240H	11H	Note	e 3:WEN polarity can be chos	sen at JP22 of I/F board
	120 line	65H	120H	15H			
	60 line	79H	6oH	17H			
	30 line	86H	30H	18H			
3-a) 60 fps = normal Ext.Trig VIDEO OUT WEN(positive) WEN(Negative)	readout	7H		4	94H	Note 1:Sync or HD is not r Note 2:1H=31.777 µ S Note 3:WEN polarity can l	be chosen at JP22 of I/F board
3-b) 120 fps = binnin	g readout						
Ext.Trig	0.032mS~40mS						
VIDEO OUT	■ 8H ■						
WEN(positive) WEN(Negative)			247H	Valid per	iod		
E	xposure time					Waiting for Ext.Tri	gger

Enlarged


TRIG XSUB Exposure time <u>1.4 ~ 1.5 μ sec.</u> 3-c) partial scan Ext.Trig 0.032mS~40mS VIDEO OUT Valid period А С В WEN(positive) 1H► Exposure time 7H WEN(Negative) Note 1:Sync or HD is not mentioned Effective readout line А В С Waiting for Ext.Trigger Note 2:1H=31.777 μ S 240 line 45H 240H 13H Note 3:WEN polarity can be chosen at JP22 of I/F board 120 line 66H 120H 17H 60 line 8oH 60H 19H 30 line 87H 30H 20H

Note : The following charts discribes the delay of the exposure

4. Pulse width control mode




4-b) 120 fps = binning readout




Waiting for Ext.Trigger

4-c) Partial scan




5. Frame-delay readout mode


Unit : 1HD (31.777 µsec.)



5-b) 120 fps = binning readout



5-c) Partial scan



7. Mode setting

7-1. SW1 switch on the rear panel

OFF	ON	[SW		Setting mode			
			no.	Switch function	OFF	ON		
		-	1					
		-	2	Shutter speed	Refer to "6-1-1.Shutter speed"			
			3					
		-	4	Binning mode	OFF	ON		
			5	Ext. trigger/readout	t Refer to "6-1-3. Ext. trigger/readout mode"			
		_	6	mode				
			7	Partial scan mode	OFF	ON		
			8	RS 232C interface	OFF	ON		

Note : The above switches are set at OFF position by factory pre-set.

7-1-1. Shutter speed	(SW1-1, SW1-2, SW1-3)

Shutter	Switch setting (OFF : \Box /ON : \blacksquare)						
speed	SM	/1-1	SW	1-2	SW1-3		
1/125							
1/250							
1/500							
1/1,000							
1/2,000							
1/4,000							
1/8,000							
1/12,000							



CAUTION

1) SW1-1, SW1-2 and SW1-3 switches are effective only when the SW1-8 switch is set at OFF position.

- 2) Exposing the CCD to direct or scattered bright light or to AC powered light, the following may appear.
 - Strong smear and/or blooming.
 - Noticeable flicker in the picture.

7-1-2. Binning mode (SW1-4)

This switch selects the Binning mode.

- OFF : Normal mode (60 frames/sec.)
- ON : Binning mode (120 frames/sec.)

At the Binning mode, please note that vertical resolution would be lower (1/2 approx.) of normal mode.

7-1-3. Ext. trigger/readout modes (SW1-5, SW1-6)

These switches select the ext. trigger/readout mode, as below.

Ext. trigger mode	Switch setting (OFF : \Box /ON : \blacksquare)				
Ext. trigger mode	SM	/1-5	SW1-6		
OFF					
Edge pre-select					
Pulse width control					
Frame-delay readout					

7-1-4. Partial scan (SW1-7)

This switch selects the Partial scan mode. The effective number of lines can be set via RS 232C, or by jumpers.

- OFF : Normal readout mode
- ON : Partial scan mode

7-1-5. RS 232C interface (SW1-7)

This switch selects the RS 232C interface.


- OFF : All functions can be set by switches and jumpers.
- ON : RS 232C interface is activated.

7-2. Jumpers on board

7-2-1. Jumpers on PK8201 board

Jumpers JP1 and JP2 are used to select the gamma setting. See table below for options. Please note that both jumpers must be in the "open" position to allow RS 232C setting of gamma. If no setting is provided via RS 232C, the camera will default to gamma 1.0.

lumpore	Setting by jumpers		Setting	Forbidden	
Jumpers	0.45	1.0	by RS 232C	Forbiaden	
JP1	Short	Open	Open	Short	
JP2	Open	Short	Open	Short	



Note : Gamma is set at "Setting by RS 232C interface" with 1.0.


Do not set the jumpers both JP1/JP2 at short circuited, as it causes a serious damge to the camera.

7-2-2. Jumpers on PK8202 board

Jumpers JP5, JP6 and JP7 enable or disable the ext. trigger input, the WEN output and pixel clock output, respectively.

lumpors	#5 of 6pin connector		#6 of 6pin	connector	#9 of 12 pin connector	
Jumpers	NC	Trigger in	NC	WEN out	NC	Pixel clock out
JP5	Open	Short				
JP6			Open	Short		
JP7					Open	Short

Function Mode		Rear Board (PK8202)						
		JP6	JP7	JP18	JP19	JP20	JP21	
Int. Sync	0	0	0/S	0/S	0/S	0	0/S	
Ext. Sync	0	0	0/S	0/S	S	0	S	
H Rest Trigger (12P)	0	0	0/S	0/S	S	0	S	
H Non Reset Trigger (12P)	0	0	0/S	0/S	S	0	S	
H Rest Trigger (6P)	S	S	0/S	0/S	0	0	0	
H Non Reset Trigger (6P)	0	S	0/S	0/S	0	S	S	
					0=0p	en S=	-Short	



H Reset Trigger Mode and H Non Reset Trigger Mode are corresponding to the following triggers: Edge Pre-select Mode, Pulse Width Control Mode, and Frame Delay Readout Mode

(12P): Trigger Mode using only 12 pin connector

(6P): Trigger Mode where 6 pin connector is used for both Trigger and WEN, and 12 pin connector is used for HD input.

JP7 and JP18 must not be SHORT at the same time.

7-2-3. Jumpers on PK8273 board

a) Jumpers JP8 thru JP13 control the input/output state as well as the termination of the HD and VD signals on pin #6 and #7 of the 12 pin connector.

Function Mode	I/F Board (PK8273)							
Function Mode	JP9	JP12	JP8	JP11	JP13	JP10		
Int. Sync	0/S	0/S	0/S	0/S	0/S	0/S		
Ext. Sync	S	0	0/S	S	0	0/S		
H Reset Trigger (12P)	0	S	-	S	0	0/S		
H Non Rest Trigger (12P)	S	0	0/S	S	0	0/S		
H Reset trigger (6P)	0	S	-	S	0	0/S		
H Non Reset trigger (6P)	S	0	0/S	S	0	0/S		

Pin no. of	#6			#7			Factory pre-set	
12pin	HD signal			VD signal				
connector	Inp	out	Output	Input		Output	#6:input	
Jumpers	75 ohm	TTL	75 ohm	75 ohm	TTL	75 ohm	#7:input	
JP8				Short	Open		Open	
JP9				Short		Open	Short	
JP10	Short	Open					Open	
JP11	Sh	ort	Open				Short	
JP12				Op	en	Short	Open	
JP13	Op	en	Short				Open	

b) Jumpers JP14 thru JP17 control the effective number of lines in the partial scan mode.


Valid period	JP14	JP15	JP16	JP17
30Line 30(V) × 648(H)	Short	Open	Open	Open
60Line 60(V) × 648(H)	Open	Short	Open	Open
120Line 120(V) × 648(H)	Open	Open	Short	Open
240Line 240(V) × 648(H)	Open	Open	Open	Short

Note : Partial scan is set at 120 (v) as factory pre-set.

c) JP22 WEN Polarity Reversing

When JP22 is set to OPEN, WEN is output, and only 1H period becomes HIGH level before video output starts. The periods from WEN output and video start may differ at each mode. When JP22 is set to SHORT, WEN's image output period becomes LOW level, and after finishing output, it becomes HIGH level.


The periods from WEN output and video start is same at each mode.




Board No. PK8273B

8. External appearance

Unit : mm (inch)







9. Specification

Model name	CV-M40
Scanning system	525 lines, 60 frames/sec.
CCD sensor	Monochorme 1/2" IT CCD sensor progressive scan
Sensing area for video out	6.4 mm (h) x 4.8 mm (v)
Effective pixels	659 (h) x 494 (v)
Cell size	9.9 (h) x 9.9 (v) μm
Resolution (horizontal)	480 TV line
Resolution (vertical)	480 TV line
Sensitivity	o.23 Lux, Max gain, 50% video
S/N ratio	48 dB (AGC OFF, Gamma=1.0)
Video output	Composite VS signal 1.0Vpp at 750hm
	Video without sync. o.7 Vpp, 75 Ohm
Gain	Auto or manual (o to + 12 dB)
Gamma	1.0 or 0.45
Synchronization	Internal X'tal., ext. HD/VD or random trig
Shutter	off (1/60) 1/125, 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/8000, 1/12000
Serial interface	RS 232C
Functions	Electronic shutter, Ext. trigger mode, Binning mode, Partial scan
Operating environment	Temperature : -5 °C to +45 °C Humidity : 20% to 80% non-condensing
Power	+12 VDC ± 10%, 5 w
Lens mount	C-mount
Dimensions	40 x 50 x 80 (HxWxD) mm
Weight	245 g approx.

Note : Above specifications are subject to change without notice.

10. Appendix

10.1. Precautions

Personnel not trained in dealing with similar electronic devices should not service this camera.

The camera contains components sensitive to electrostatic discharge. The handling of these devices should follow the requirements of electrostatic sensitive components.

Do not attempt to disassemble this camera.

Do not expose this camera to rain or moisture.

Do not face this camera towards the sun, extreme bright light or light reflecting objects. Even when this camera is not in use, put the supplied lens cap on the lens mount.

Handle this camera with the maximum care. Operate this camera only from the type of power source indicated on the camera.

Power off the camera during any modification such as changes of jumper and switch setting.

10.2. Typical CCD Characteristics

The following effects may be observed on the video monitor screen. They do not indicate any fault of the CCD camera, but do associate with typical CCD characteristics.

V. Smear

Due to an excessive bright object such as electric lighting, sun or strong reflection, vertical smear may be visible on the video monitor screen. This phenomenon is related to the characteristics of the Interline Transfer System employed in the CCD.

V. Aliasing

When the CCD camera captures stripes, straight lines or similar sharp patterns, jagged image on the monitor may appear.

Blemishes

Some pixel defects can occur, but this does not have en effect on the practical operation.

Patterned Noise

When the CCD camera captures a dark object at high temperature or is used for long time integration, fixed pattern noise (shown as white dots) may appear on the video monitor screen.

11. User's Record

Camera type:	CV-M40
Scanning system:	EIA
Revision:	(Revision C)
Serial No.	

Users Mode Settings

Users Modifications

This manual can be downloaded from: www.jai.com

JAI A-S, Denmark Produktionsvej 1, 2600 Glostrup Copenhagen, Denmark Phone +45 4457 8888 Fax +45 4491 8880 www.jai.com

JAI Corporation, Japan

JAI Corporation, Japan German Industry Center 1-18-2 Hakusan, Midori-ku Yokohama, Kanagawa 226-0006, Japan Phone +81 45 933 5400 Fax +81 45 931 6142 www.jai-corp.co.jp

JAI America, Inc., USA

Suite 450 23046 Avenida de la Carlota Laguna Hills, CA 92653 USA Phone +1 949 472 5900 Fax +1 949 472 5908 www.jai.com

